

RO

Pentru utilizare casnică doar în aer liber

- Etapa 1: pentru vârsta de 9-18 luni.
- Etapa 2: pentru vârsta de 18-36 luni.
- Etapa 3: pentru vârsta de 3-5 ani.
- Etapa 4: pentru vârsta de 5 ani în sus.

ATENȚIE

Nu utilizați leagănul Multi-Stage până când nu a fost instalat corect de către un adult în conformitate cu aceste instrucțiuni.

Asigurați-vă că copiii sunt îmbrăcați în mod adecvat, pentru a evita pericolele potențiale în timp ce utilizează leagănul. Copiii nu ar trebui să poarte haine largi, cum ar fi poncho sau eșarfe.

Plasați numai un singur copil de fiecare dată pe leagănul Multi-Stage.

Nu lăsați niciodată nesupravegheat un copil în leagănul Multi-Stage.

Pentru etapele 3 sau 4: Deconectarea "T-Bar" ar trebui să fie doar atunci când copilul nu este așezat în leagăn.

Atunci când copilul este așezat în leagăn asigurați-vă că pârghiile de eliberare sunt complet blocate.

Acest leagăn trebuie să fie instalat deasupra unui teren moale - adică nu beton sau asfalt.

INSTRUCȚIUNI DE INSTALARE

Puneti pe o suprafață plană îndepărtată de cel puțin 2 metri de orice structură sau obstrucție, cum ar fi un gard, garaj, casa, ramuri suspendate, sfori de rufe sau fire electrice.

La asamblare, suspendați acest leagăn din puncte adecvate ce pot purta greutatea utilizatorului destinat și prin mijloace sigure.

Înălțimea accesibilă maximă a structurii nu trebuie să depășească 2,5 metri de sol, înălțimea recomandată este de 2,2 metri de sol.

Distanța minimă dintre multiple leagăne și între leagăne și structurile alăturate nu trebuie să fie mai mică de 30 cm.

Distanța minimă între leagăn și orice obiecte suspendate de un singur punct de suspensie (de exemplu, sfoară de cățărat), nu trebuie să fie mai mică de 45 cm.

Baza leagănelui trebuie suspendată cel puțin 35 cm de la nivelul solului.

Pentru a atinge stabilitatea laterală a leagănelui, el trebuie să fie suspendat de puncte care sunt separate de o distanță minimă calculată după cum urmează:

= Distanța $(0,04 \times \text{înălțimea de suspendare de la sol}) + \text{lățimea de suspendare}$, la scaun 37 cm.

ÎNTREȚINERE

La începutul fiecărui sezon verificați scaunul leagănelui, frânghiile și celelalte mijloace de echipament de urme de deteriorare.

Verificați periodic punctele de suspensie principale altfel acest lucru poate duce la răsturnarea produsului sau la o cădere.

Modificările făcute leagănelui original (de exemplu adăugarea unui accesoriu) se efectuează în conformitate cu instrucțiunile vânzătorului leagănelui. Înlocuiți atunci când este necesar, în conformitate cu instrucțiunile producătorului.

Păstrați aceste instrucțiuni de asamblare și de instalare pentru referințe ulterioare.

EN

For family domestic outdoor use only

- Stage 1: for ages 9-18 months.
- Stage 2: for ages 18-36 months
- Stage 3: for ages 3-5 years.
- Stage 4: for ages 5 years and up.

WARNING

Do not use the Multi-Stage swing until it has been properly installed by an adult according to these instructions. Be sure children are dressed appropriately to avoid potential hazards while using the swing. Children should not wear loose fitting clothing such as ponchos or scarves. Place only one child at a time in the Multi-Stage swing. Never leave child unattended while in the Multi-Stage swing. For stages 3 or 4: Disconnecting the "T-Bar" should be only when the child is not seated. When the child is seated in the swing ensure that the release levers are fully locked. This swing should be installed over soft ground – i.e. not concrete or tarmac.

INSTALLATION INSTRUCTIONS

Place on a level surface at least 2 meters from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires. When assembling, suspend this swing from points suitable for bearing the weight of the intended user and by secure means. The maximum reachable height of the structure should not exceed 2.5 meters from ground, the recommended height is 2.2 meters from the ground. The minimum clearance between any multiple swings and between swings and their adjacent structures should not be less than 30 cm. The minimum clearance between the swing and any members suspended by a single suspension point (e.g. climbing rope) should not be less than 45 cm. The swing base should be suspended at least 35 cm from ground level.

To achieve lateral stability of the swing, the item should be suspended at points which are separated by a minimum distance calculated as follows: Distance = (0.04 x the height of suspension from ground) + the width of suspension at the seat 37 cm.

MAINTENANCE

At the beginning of each season check swing seat, ropes and other means of attachments for evidence of deterioration. Regular checks of the main suspension points should be carried out otherwise this may result in the product overturning or in a fall. Changes to the original swing (for example the adding of an accessory) shall be carried out according to the instructions of the retailer of the original swing. Replace when required in accordance with the manufacturer's instructions.

Keep these assembly and installation instructions for further reference!