



Montážny návod — BONET


1




2




3



4



5



A		1	I		1
B		2	J		1
C		1	K		6
D		1	L		1
E		2	M		1
F		4	N		1
G		12	O		1
H		4	P		6