










Montážny návod - ASPER NEW DT8011-120 140




Ax4	Bx4	Cx4	Dx8	Ex1	Fx4
					
M8x730	M8	M8			


1



2



3



4

