




Montážny návod **FLOKI** pc stôl TB6808



Časť C

Časť B





Časť C



Časť A

Montážny návod **FLOKI** pc stôl TB6808

#1: 1ks	#2: 1ks	#3: 2ks	#4: 2ks	#5: 6ks	#6: 5ks
#7: 1ks	#8: 3ks	#9: 1ks	#10: 1ks	#11: 1ks	#12: 5ks
#13: 1ks	#14: 1ks	#15: 30ks	#16: 30ks		



Časť A



Časť B