




# INSTRUCTIUNI MONTARE







## AVERTISMENT:


1. Capacitate de sustinere: 5 -8 kg
2. In caz de folosire necorespunzatoare exista riscul de a se prabusi/ darama.
3. Supravegheati copiii mici!









	<b>A x 1</b>			<b>B x 26</b>	<b>M6*16mm</b>
	<b>C x 4</b>	<b>M8*12mm</b>		<b>D x 2</b>	<b>M6*18mm</b>
	<b>E x 1</b>			<b>F x 1</b>	
	<b>G x 4</b>			<b>H x 4</b>	
	<b>I x 2</b>			<b>J x 2</b>	
	<b>K x 2</b>			<b>W x 1</b>	
	<b>V x 1</b>			<b>X x 1</b>	
	<b>Y x 1</b>			<b>Z x 1</b>	

1





						
<b>B x 14</b>	<b>E x 1</b>	<b>I x 2</b>	<b>J x 2</b>	<b>H x 4</b>	<b>Y x 1</b>	<b>Z x 1</b>

2



3




**B x 4**



**E x 1**

4





**K x 2**




**B x 4**

5



Bx4



Cx4




Fx1




Gx4

6



Cablul USB  
trebuie  
conectat la un  
calculator sau  
laptop.


! Nu se  
recomanda  
conectarea  
cablului la un  
incarcator sau  
la alte  
dispozitive  
decat cele  
recomandate  
mai sus.



Xx1



Ax1



Dx2



Wx1



Vx1